

# **Effects of Core-Shell Rubber(CSR) nanoparticles on the Cryogenic**

## **Fracture Toughness of CSR modified epoxies**

**J. Wang, D. Magee, J.A.Schneider**  
**Department of Mechanical Engineering**  
**Mississippi State University**

### **ABSTRACT**

This study investigated the effects of core-shell rubber (CSR) nanoparticles on the mechanical properties and fracture toughness of an epoxy resin at ambient and liquid nitrogen (LN<sub>2</sub>) temperatures. Varying amounts of Kane Ace® MX130 and Kane Ace® MX960 toughening agent were added to a commercially available EPON 862/Epikure W epoxy resin. Elastic modulus was calculated using quasi-static tensile data. Fracture toughness was evaluated by the resulting breaking energy measured in Charpy impact tests conducted on an instrumented drop tower. The size and distribution of the CSR nanoparticles were characterized using Transmission Electron Microscopy (TEM) and Small Angle X-ray Scattering (SAXS). Scanning Electron Microscopy (SEM) was used to study the fracture surface morphology. The addition of the CSR nanoparticles increased the breaking energy with negligible change in elastic modulus and ultimate tensile stress (UTS). At ambient temperature the breaking energy increased with increasing additions of the CSR nanoparticles up to 13.8wt%, while at LN<sub>2</sub> temperatures, it reached a plateau at much lower CSR concentration.

# ***Effects of Core-Shell Rubber(CSR) Nanoparticles on the Cryogenic Fracture Toughness of CSR Modified Epoxy***

**Jun Wang, D. Magee, Judy Schneider**



**Department of Mechanical Engineering  
Mississippi State University**

# Outline

- 1. Background**
- 2. Experimental Procedures**
- 3. Results**
- 4. Summary**



# **Polymeric composites are candidates for storage of high pressure, cryogenic fuels**



- **LH<sub>2</sub> Storage (20K)**
- **LOX Storage (90K)**
- **Liquefied Natural Gas (113K)**
- **LN<sub>2</sub> (77K)**

# **Objective**

**Investigate low cost testing methods to evaluate and identify promising material properties of interest in the fabrication of cryogenic composite overwrapped pressure vessel (COPV)**

**Screening methods for selection of suitable materials include:**

- Quasi-static mechanical properties**
- Dynamic impact test**

# **Improving fracture toughness of polymeric resins at cryogenic temperatures**

**Fracture toughness of polymeric resins has been improved at ambient temperatures by the addition of nanoparticles such as:**

- exfoliated clays**
- carbon nanotubes**
- core-shell rubber nanoparticles**

**This study investigates the effectiveness of CSR particles on the fracture toughness of an epoxy based resin at cryogenic temperatures.**

**EPON 862/ Epikure W epoxy resin  
was cast with varying amounts of  
Kane Ace® MX130 toughening agent**

**Specimens:**

- 1. 0 wt. % - Neat Resin*
- 2. 1 to 13.8 wt. % addition of  
- CSR rubber tougheners*



Specimens cast for:

Uniaxial tensile tests (3 mm thick)

Charpy impact tests (10 mm thick)

# Microstructure Characterization

## ➤ Transmission Electron Microscopy (TEM):

- Representative bulk samples

## ➤ Small Angle X-ray Scattering (SAXS):

- Larger sample size to investigate homogeneity




## ➤ Scanning Electron Microscopy (SEM):

- Fracture surface of Charpy impact test specimens








# SAXS analysis confirmed CSR nanoparticles size and distribution




EPON 862/W MX130 with 9.2 vol.% CSR additives



# Fracture mechanisms were studied by SEM images



neat resin  
featureless wave-like fracture steps



862/W-1 vol.%  
jagged and scale-liked edges

**SEM images of Fracture surfaces of Cryogenic Charpy Impact test specimens**

# **Mechanical properties evaluated using quasi-static, uniaxial tension testing**



**MTS extensometer attached to specimen mounted in grips.**




**Interior of cryostat.**



**Cryostat mounted on Instron load frame.**

- **Instron Model 5869 EM**
- **50 kN load cell**
- **MTS Model 634 extensometer**
- **Constant velocity 0.13 cm/min**
- **ASTM Standard D638**


# Negligible Elastic Modulus and UTS of small additions of CSR at ambient temperature




**Future test will include the cryogenic temperatures**

# Charpy impact test to evaluate fracture toughness

## Un-Notched Specimen




INSTRON Dynatup 9250HV  
Instrumented Drop Tower



*ASTM Standard D6110*

- **Specimen Temperature: 77-100K**
- **Impact speed: 216 m/min**
- **Energy: 58 Nm**

# Charpy impact test results for MX130



EPON 862/Epikure W



# Summary

- ***Using Kane Ace® MX130, a 1 wt.% addition of CSR nanoparticles resulted in the maximum increase in the impact resistance measured during an instrumented Charpy impact test at cryogenic temperature.***
- ***TEM and SAXS characterization of these specimens verified the particle size distribution and volume fraction of the CSR in the epoxy matrix.***
- ***SEM images showed differences in the fracture surface morphology which corresponded with the increased impact resistance associated with the additions of CSR nanoparticles.***
- ***Future work included Kane Ace® MX960 will be tested for the comparing.***
  - ***Kane Ace® MX960 may have better performs at cryogenic temperature.***



# Acknowledgements

- **Mr. Doug Sober of Kaneka Texas for providing the evaluation materials.**
- **Funding provided by the MSU Hearin (JW) and Mississippi Space Grant Consortium (DG ).**
- **X-ray diffractometer obtained with NSF-MRI Grant # DMR-0619773 (2006) and FE-SEM was purchased under NSF-IMR Grant #DMR.0216703 and 02070615.**

